

PD2 Insulated Personnel Door - Installation Instructions

The frame must be installed on a horizontal plane. If the floor slopes, start by settling the frame on the high side first. Shim to raise the other side so that the top of the frame is level. Proper installation depends on the frame being level and plum. Drill $\frac{3}{8}$ " holes where shown and secure in place with carriage bolts, washers and nuts supplied with the door. Use caulking around the frame to provide a vapor seal between the wall and the frame.

