

UNDERSTANDING SMARTRITE® DISPLAY ICONS

Easily decode your unit's display icons and stay on top of system performance with this quick reference guide.

The SmartRite® system provides real-time monitoring of temperature and humidity conditions, along with access to system status, alarms, lighting controls, and other available features. Use this reference as a convenient tool for navigating the display and interpreting on-screen indicators during daily operation.

For detailed information on installation, setup, system configuration, advanced features, troubleshooting, and remote monitoring capabilities, please refer to the SmartRite Installation and Operation Manual and other related SmartRite documentation.

Note: Features shown on the display may vary depending on your system configuration and installed options.






Display Navigation		
	Icon	Description
1		Displays that the connection status is connected to the server
		No Wi-Fi network was selected = No SSID and password was saved by the system
		Wi-Fi with no internet
		Wi-Fi Not Configured
2		Wi-Fi Connected to the internet
		Signal Strength: Displays the current Wi-Fi signal in decibels (see lower table)
3		Battery Status: Displays current battery charge level
4		Clock: Displays current time and date
5		Temperature Unit: Displays in Fahrenheit or Celsius
6		Humidity: Displays percentage of relative humidity
7		Trumpet Button: Used to acknowledge and silence alarm

Signal Strength	RSSI (dBm)	Meaning
Excellent	-32 to -70 dBm	Ideal for SmartRite online services.
Good	-71 to -80 dBm	SmartRite online services may be impacted.
Fair	-81 to -90 dBm	SmartRite online services will be impaired.
Weak	Below -90 dBm	SmartRite will be unable to connect.

UNDERSTANDING SMARTRITE® DISPLAY ICONS

Easily decode your unit's display icons and stay on top of system performance with this quick reference guide.

Display Navigation		
	Icon	Description
8		Motion Detection: When the chamber is occupied, the motion detector will keep the lights illuminated beyond the run-light timer
9		UV Icon: UV disinfection device active
10		Light Button: Used to turn optional lights on or off
11		Evap. Fan Button: Used to enable evaporator fan
		Prohibition Icon: Indicates function disabled
12		Menu Button: Used to display main menu
13		Notification Bar: Indicates system alarm
14		Open Door: Open Door icon shows the door is currently open at the assign door (Door 1, Door 2). If closed – the icon is hidden.
15		Door Frame Heater: Indicate that the door heater on the assign door is energized
16		Temperature: Displays current temperature in room
17		Room Type: Displays room type



Alarms

When an alarm is triggered, the notification bar turns red and an audible alert sounds. Tap the notification bar to view active alarms. Press the trumpet icon (#7) to acknowledge the alarm and silence the sound.

Once system conditions return to normal, the alarm will clear from the list.